



## Product Parts


1 - Table Throw



FRONT




BACK



## Display Set-Up


### Step 1

Remove the Table Throw (1) from the bag and place on table.




### Step 2

Insert the feet of the table into the pockets located on the bottom inside corners of the throw.



### Step 3


After inserting all four table feet into the pockets, close the back zipper.



## Storage


### Step 1

Unzip the back zipper.




### Step 2

Remove all four table feet from the pockets.



### Step 3

Remove Table Throw (1) and fold. Place into a Carry Case (sold separately) and store in a cool, dry location.



## Care

Recommended for indoor use only.

Machine wash on gentle cycle using mild detergent. Tumble dry low-heat setting only. Do not dry clean. Do not iron.

*Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.*