
LIGHTBOX DISPLAYS

GLM SELECT - 10 FT SEG POP UP DISPLAYS

PRODUCT CODE: OC-SEG4X3




INSTRUCTIONS




GLMDISPLAYS


• Place frame with the adjustable feet facing down. Expand the frame.




• Close frame by pushing the outside of the frame until male and female ends connect. Repeat for all connectors.



• Connect the top and bottom End Caps on each side of the frame.



• Expand each Channel Bars. Follow bungee to connect.



• Attach channel bars to frame. Slide channels bars onto frame, from top to bottom, then secure onto metal peg.



• Snap the Edge Lights on each bottom middle "x" bars.


LIGHTBOX DISPLAYS

GLM SELECT - 10 FT SEG POP UP DISPLAYS

PRODUCT CODE: OC-SEG4X3



INSTRUCTIONS




GLMDISPLAYS

• Then snap the Edge Lights on each top middle "x" bars.



• Plug the Jumper Cords into the top and bottom Edge Lights together.



 Connect the Jumper Cord to the Transformer using the barrel connectors.





• Insert power cord to the Transformer. Plug other side into your main power outlet (Once graphics are installed onto the frame).



• Install one piece graphic on the front side of the frame. Start on each corner of the end caps. Insert the silicone edge beading into the groove corners (top & bottom). Repeat graphic installation on other side the end caps.



• Then insert the remainder of the beadings of the one piece graphic. Repeat graphic installation on the back side of the frame.