# SKYCAP UMBRELLA (SQUARE)













### PRODUCT DESCRIPTION

The Skycap Umbrella Square frame is constructed of a steel pole with aluminum and plastic components. On top is a plastic finial hub and on the bottom is a plastic runner, which slides up to a latch to lock into place. The Skycap easily stands free with the use of a universal umbrella table. No umbrella table? Add an optional iron square base accessory to make your umbrella free-standing. Skycap umbrellas serve as an excellent way to provide shade for outdoor events. The graphic is printed on special water resistant material and dries immediately during the UV-cured printing process. Finished prints appear shiny, vivid, and have added protection against natural elements.

DISPLAY DIMENSIONS	110.5" Dia. x 86"H (1.5" Pole Diameter)

GRAPHIC SIZE 80"W x 40"H (each side)

### **GRAPHIC MATERIAL**

**UV** Tent

### **GRAPHIC FINISHING**

Hemmed around sides and bottom edges

### **DISPLAY CONSTRUCTION**

Steel pole with aluminum and plastic components.

### SHIPPING WEIGHTS & DIMENSIONS

	9 lbs (hardware only) 11 lbs (with graphic)
Shipping Dimensions	7"L x 7"W x 62"H

### LARGE QUANTITY FREIGHT

Freight Shipping	20 boxes per 48"L x 40"W x 40"H skid
Freight Weight	216 lbs (frame only)
	258 lbs (frame and graphic)

### **GRAPHIC TURN AROUND TIME**

4 business days after proof approval

### AVAILABLE ACCESSODIES

AVAILABLE ACCESSORIES	
Iron square base	
AVAILABILITY	CA
WIND RATING	20 mph



Finial







Iron Square Base (optional)

# PARTS LIST



(qty 1) Umbrella frame



(qty 1) Lower extension

# SET UP INSTRUCTIONS

(HEXAGON SKYCAP SHOWN BELOW)

### Step 1

Start by installing the umbrella onto the frame. Locate the finial at the top of the frame and remove it.



### Step 2

Unravel the umbrella and place it over the frame. Align the opening at the peak with the hole from which the finial was removed.



### Step 3

Slightly screw the finial back on. Do not tighten it completely.



### Step 4

Locate the tabs that are sewn on the inside of the umbrella. Slide each rib into a tab until all of them are securely in place and then tighten the finial.







Insert the lower shaft by holding the push-out cap in and then sliding the shaft on until the cap forces itself out. To open up the umbrella, slide the runner up the shaft until it locks onto the latch. Press the button and slide the runner back down to close the umbrella.





### Step 6

The umbrella is ready to be fitted to either a steel base, table, or both for optimal support.

