


# Four Season Event Cooler Table

Kit Item #: 280299  
Hardware Item #: 280300  
Graphic #: Top & Bottom: 280301, Top: 280302, Bottom: 280303

## Product Parts

- 1 - Cooler (x1)
- 2 - Bottom Graphic (x1)
- 3 - Top Graphic (x1)
- 4 - Phillips Screws (x4)
- 5 - Legs (x4)



\*Standard Phillips screwdriver is needed for assembly (not included)

**COOLER ONLY AVAILABLE IN WHITE**



## Display Set-Up


### Step 1

Unpack all product parts from the box and make sure you have the Cooler (1), Four Screws (3) and Four Legs (4).



### Step 2


Begin by turning the cooler upside down and insert the legs into the leg holsters as shown. Using the four Phillips Screws (4), attach the four legs (5) to the cooler (1). Get the screws started first, then tighten them using a standard Phillips screwdriver. Do not over-tighten and **DO NOT USE** a powered drill.



### Step 3


Unpack the Bottom Graphics (2) and lay on a clean surface. Set the legs of the cooler inside the open areas of the graphic as shown.

Slide the graphic up and secure the elastic around the top edge of the cooler, just below the table top. as shown.



### Step 4

Unpack the Top Graphic (3) and stretch over the top of the cooler securing the elastic over the lip of the cooler top as shown.




## Display Set-Up Continued

### To Lock the Lid

To lock the lid in place, lift the lid all the way up to its full table height and turn the locking dial counter-clockwise until it stops as shown.

To lower the lid, simply un-lock the dial and carefully slide the top of the cooler down.



### To Drain the Cooler

Locate the drain plug on the inside-bottom of the cooler. Carefully lift up on the plug until it stops.

NOTE: Plug will not come completely off the cooler.

