Vector Frame Essential Light Box Square 01

VF-ESS-LB-S-01

Vector Frame™ fabric light boxes feature durable 120mm (4.75") aluminum extrusion frames, push-fit backlit fabric graphics and LED top and bottom lighting. Single and double-sided graphic options are available. LED lights come adhered to the frame making set-up as simple as assembling the frame, applying the push-fit graphics and plugging in the electrical cord!



features and benefits:

- White aluminum frame
- Pre-attached LED lights
- Swivel feet for stability
- Easy toolless assembly

- Reusable box with foam padding and builtin plastic handle
- One year frame warranty against manufacturer defects
- 90 day light warranty

dimensions:


difficitions.	
Graphic	
Refer to related graphic template for more information.	
One year warranty.	
Visit: https://www.theexhibitorshandbook.com/ download-graphic-templates	
additional information:	
Graphic material: Backlit Intensity push-fit fabric graphics	
Lighting Power Requirements: Watts Amps Volts: needed: needed: 120-240V 150W 6.25A	

We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.



This product may include the following materials for recycle: aluminum, select wood, fabric, cardboard, paper, steel, and plastics.


Included In Your Kit



Swivel the feet of the Bottom Extrusion. ■


Do not have the Power Cord * plugged into a power supply while assembling.

It is recommended to assemble the frame flat on the floor.




Fit the Bottom Extrusions together.

Fit the Side Extrusion Bottoms onto the Bottom Extrusion connectors.





Fit the Side Extrusion Tops ▲ onto the Side Extrusion Bottom ● connectors.




Fit the Top Extrusions together.

Fit the Top Extrusions onto the Side Extrusion Top connectors.






Fit the Channel Bar 🔷 assembly into place on the Top, Bottom, and Side Extrusions.




Connect the light power cords according to the diagram on the right.

the Cross Piece.



Fit your graphic(s) into the channel on the top and bottom extrusions.



Tilt the frame up.

Connect the Power Cord * to the cable at the bottom

Then connect to the power supply.

of the frame.

Set up is complete.

